







Bonus points are based on how quickly you disting

of mission on first planet of player's choice. Super Bo-nus points are based on the difficulty of the first planet completed, with each planet in the first solar system.

Operator Options

Game Difficulty. Advisorable for "Fasty" or "Hard"



tate Left and Thrust Press Fire for shots, single shot per button pressure. ShieldThactor used to protect ship and to acquire fuel cells.

Game Livea, Operators may suject 3, 4, 5 or 6 ships Bonus Levels, Salectable for 4 bonus levels including 'No Bonus', Borus every 10,000 points. Borus every

Self-Test. Allows operators to check all game switches

Coln Modes, Includes 17 unique operator-selectable

Gravitar Upright, Height 71.74*, 182.2 cm., Width 25.25*, 64.14 cm., Depth 31.59*, 97.23 cm., Weight 307 ibs., 139.2 kg. Montor: 19* QuadraScarl*Cobr European: Height 681, 172 7 cm., Width 25 251, 64 1 cm. Depth 311, 78 7 cm., Weight 275 lbs., 124 7 kg.



High Soore List, Co-Pilot List records 8 top



Distributed By: